

Oxbury Bridge



Installation:

1. Screw the hot and cold water inlets (C) into the base of the bridge (A), use rubber seals (B) to create a water tight seal between the parts.
Note: the nuts on the base of the bridge (A) should be tightened to the inlet legs when they are rotated to give the required center distance. Protect the nut from scratching when tightening using a cloth or similar.
2. Pass the base plinths (D) over the inlet legs (C) to the end of the threaded section before the bend. Ensure rubber O-rings (E) are inserted into the base of base plinths (D).
3. Place the bridge (A) onto the sink or worktop and pass the threaded inlet pipes (C) through the tapholes. With the tap in place check that the inlet pipes (C) meet the hot and cold water feeds. If further adjustment to the plumbing is required do this now. The hot water should be connected to the left hand side of the tap when viewed from the front.
4. Pass lower seals (F) over the inlet legs (C) flush to the underside of the sink or worktop.
5. Fasten the fixing nuts (G) securely onto inlets (C) fixing the tap into its correct location.
6. Connect the inlets (C) to the water supplies using 1/2" BSP compression fittings or similar.

Changing aerator:

The tap can be fitted with a 5 lpm aerator (I). To switch from standard flow (A2) to the 5 lpm (L) follow steps below:

1. Unscrew aerator case (A1) by hand.
2. Replace standard flow aerator (A2) with 5 lpm flow aerator (I).
3. Screw aerator case (A1) back onto spout ensuring seal (A3) is in place as shown.

Changing Lever design:

1. Unscrew decorative top (A6) by hand and pull horizontally away from handle base stem (A4).
2. Replace Ceramic handle (A5) with solid metal handle (H) onto stem of handle base (A4).
3. Screw decorative top (A6) onto top of handle base stem (A4) to tighten handle in place.

After Installation:

Once you have visually checked the new fittings and connections, ensure that all taps and drains are closed except the new product which should be **left open**. Turn on (reconnect) the water supplies, check carefully for leaks around the installation and product function. Once you are sure of no leaks, close the new product and recheck for leaks, turn on the water heating power.

Clean and dry the product of any marks from installation then cover the product with the bag provided to protect it until use.

Important Technical Data

Minimum operating pressure:

0.2 bar (Standard aerator) 1.5 bar (With flow limiter)

Maximum operating pressure: 5 bar*

Flow characteristics: Single flow

Maximum hot water temperature: 60°C*

Recommended hot water temperature: 46°C

*If these temperatures or pressures are exceeded, even for short periods, damage can result and will void your warranty. In these instances, reduce the incoming water temperature and or install a pressure reducing valve. Ensure that your Abode product is fitted in accordance with Local Water Byelaws or regulations by a qualified installer.

These installation guidelines have been prepared for your direction and you must exercise due care at all times. We do not accept responsibility for problems that may occur through improper installation. Whilst installing the product take care not to accidentally loosen any screwed assemblies.

Manufacturers Product Reference: AT2223, AT2224, AT2225

©Abode - 03/2024

Warranty:

All Abode products are made using the highest quality materials and components, to ensure that they meet or exceed all UK or European Standards.

All products are thoroughly tested, and quality checked.

All products are backed with a comprehensive warranty and we are confident that they will give many years of trouble-free service.

The warranty applies to products used for normal domestic purposes and where the installation, care and maintenance instructions have been observed.

The warranty extends to the original purchaser only.

Details of Warranty duration and Terms & Conditions for each product type can be found on our website (www.abodedesigns.co.uk).

Important Care Instructions for your Product:

To maintain the appearance of this product, ensure that it is regularly cleaned only using a clean, soft damp cloth. A solution of warm water and a mild liquid detergent may be used where necessary, and then the fitting rinsed thoroughly and wiped dry. Any other cleaning action or use of common domestic cleaning products will invalidate your warranty.

If the product has a plastic aerator insert at the end of the spout it should be unscrewed and the plastic internal insert only removed and cleaned or descaled to maintain flow performance. Do not use descaling solution on any decorative metal housing, rinse the insert thoroughly before reattaching in the reverse order.

Abrasive cleaners, scouring cleaners and acidic cleaners **must not be used on this product** under any circumstances. Avoid contact with all solvents (including chlorinated solvents, ketones or acetones as these may result in surface deterioration or etching). Also avoid contact with any harsh household chemicals such as oven cleaners, drain cleaners, rust removers, paint strippers and toilet bowl cleaners, bar keepers friend or Brasso.

Please leave these instructions for your customer.

Parts and Contents:

Key	Description	Qty
A	Bridge	1
B	Rubber seal	2
C	Hot & Cold water inlets	2
D	Base plinth	2
E	Rubber O-ring	2
F	Lower sink seal	2
G	Fixing nut	2
H	Solid metal handle pack	2
I	5 Litres per minute aerator	1

Installation Instructions:

Preparation

Before installing the new product it is essential that you thoroughly flush through the supply pipes in order to remove any remaining solder, swarf or impurities from your system. Failure to carry out this simple procedure could cause problems or damage to the workings of the product or reduce performance invalidating the warranty.

We strongly recommend best practice of installing particle filters and isolation valves to both the hot and cold feed pipes in an accessible position. This will help to prevent premature failure of the valves and ease any future maintenance.

All parts should be removed from their packaging and inspected for any transport damage prior to installation.

Shut off (isolate) your hot and cold water supply locally at the point of installation before continuing with the installation. If the water cannot be isolated locally then turn off the mains stopcock and power to any heating system, now open the lowest tap or drain point in the system until both hot and cold supplies are fully drained.

This product requires two 35mmØ tap holes, the centre spacing is 203 – 257mm, the nominal centre spacing is 203mm. If replacing an existing product, remove it and clean the end of the hot and cold feed pipes using wire wool, the tap hole area should be free from dirt and sealant.

Loosely position the product and fittings to check if any alteration to the existing pipework is required, if needed, do this now.

If the product is single flow (see section important technical data “flow characteristics”) then non return (check) valves must be installed to comply with regulations. Some products are supplied with non-return valves this will be noted in the instructions.

