



Mayenne 3 Part



General Advice:

- These instructions are intended as a guide only, if you are in any doubt you should seek the advice of a qualified professional.
- Take care not to mark finished parts with screwdrivers or other tools.
- Use a pair of rubber gloves to get a better grip on decorative hand tight parts.
- Ensure all parts are reassembled tightly.
- After maintenance test that all assemblies are water tight and function correctly.
- Always isolate the hot and cold water supplies before starting any maintenance, once isolated you should drain any residual water from your system.

To replace the cold valve:

- 1. Loosen grub screw (D1) on the side of handle (D2) using a 2.5mm A/F Allen key.
- 2. Pull handle (D2) vertically away from the body (B1).
- 3. Unscrew decorative cover (D6) by hand and away from valve (D7).
- 4. Using an adjustable spanner or socket unscrew valve (D7) anticlockwise.
- 5. Replace the faulty valve (D7) with the new one and assemble in reverse order.

To replace the spout O-rings:

- 1. Loosen grub screw (A10) on the rear of body (B1) using a 2.5mm A/F Allen key.
- 2. Pull the spout (A4) vertically away from the body (B1).
- 3. Remove the old O-rings (A7 & A8) using a small screwdriver or similar.
- If worn, remove the white PTFE spacers (A6 & A9).
- 5. Ensure the inside of the body (B1) and the spout base is clean of dirt and grit with a soft wet cloth.
- 6. If required locate the new white PTFE spacers (A6 & A9).
- Carefully locate the new O-rings (A7 & A8) onto the spout base (A4).
- 8. Grease the O-rings thoroughly with silicone or alternative similar grease.
- 9. Reassemble the tap in the reverse order.

To clean the aerator:

- 1. Unscrew the aerator housing (A1) by hand.
- 2. Clean the aerator (A2).
- 3. Screw aerator case (A1) back onto spout ensuring seal (A3) is in place as shown.

To replace the aerator with a flow limited aerator:

- 1. Unscrew aerator case (A1) by hand.
- 2. Replace standard flow aerator (A2) with 5 lpm flow aerator (A11).
- 3. Screw aerator case (A1) back onto spout ensuring seal (A3) is in place as shown.